


Socket head Plug


Male thread : BSPP (G) - ISO 228



| Part No. | G<br>Male<br>thread<br>BSP | Ød3 | i  | L2 | S6 |
|----------|----------------------------|-----|----|----|----|
| VST IG01 | G 1/8                      | 14  | 8  | 11 | 5  |
| VST IG02 | G 1/4                      | 18  | 12 | 15 | 6  |
| VST IG03 | G 3/8                      | 22  | 12 | 15 | 8  |
| VST IG04 | G 1/2                      | 26  | 14 | 18 | 10 |
| VST IG06 | G 3/4                      | 32  | 16 | 20 | 12 |
| VST IG08 | G 1                        | 39  | 16 | 21 | 17 |
| VST IG10 | G1 1/4                     | 49  | 16 | 21 | 22 |
| VST IG12 | G1 1/2                     | 55  | 16 | 21 | 24 |

Socket head Plug with Elastomeric Seal

Male thread : BSPP (G) - ISO 228



| Part No.  | G<br>Male<br>thread<br>BSP | Ød4 | i  | L1 | S3 |
|-----------|----------------------------|-----|----|----|----|
| VST IG01E | G 1/8                      | 14  | 8  | 13 | 5  |
| VST IG02E | G 1/4                      | 19  | 12 | 17 | 6  |
| VST IG03E | G 3/8                      | 22  | 12 | 17 | 8  |
| VST IG04E | G 1/2                      | 27  | 14 | 20 | 10 |
| VST IG06E | G 3/4                      | 32  | 16 | 22 | 12 |
| VST IG08E | G 1                        | 40  | 16 | 24 | 17 |
| VST IG10E | G1 1/4                     | 50  | 16 | 24 | 22 |
| VST IG12E | G1 1/2                     | 55  | 16 | 24 | 24 |