

Repair instructions series EBV

Dismantling the accumulators

- Disconnect and close the accumulators inlet and discharge the hydraulic fluid from the accumulators.
- Remove the accumulators from its mounting and lay it horizontally in a vice or other fixation system. Take care not to damage the accumulators.
- Unscrew the protective cap (**Fig. 1**).
- Unscrew the gas valve cap (**Fig. 2**).
- Deflate the bladder using OLAER tester and pressurize instrument (**Fig. 3**). Operate the tester and pressurize instrument as described in its manual.
- Remove the gas valve (**Fig. 4**).
- Release the gas inlet valve sub-assembly nut and remove the name plate (**Fig. 5**).
- Unscrew the flange or reduction from the hydraulic fluid end (not used with every model).
- **With the accumulator completely free of pressure (gas and fluid), a loose fit of the grid has to be detected. If this is not the case all further work has to be stopped! Please contact OLAER!**
- Remove the spring ring (**Fig. 6**).
- Remove the grid (**Fig. 7**).
- Extract the bladder through the hydraulic end opening. (**Fig. 8**).



Cleaning, inspection and repairs

- Carefully clean all metallic parts of the accumulators and dry with compressed air.
- Inspect the vessel from any internal damage.
- Check that the O-ring shows no sign of wear or any indication of rubbing.
- Check that the bladder has no sign of major frictional wear or other damage.
- Under no circumstances attempt to repair the bladder.
- Replace all worn or damaged parts.

Assembly

- Ensure that no foreign bodies are in the accumulator.
- To facilitate the reassembling of bladder, smear it and vessel interior with the system hydraulic fluid.
- Press the upper part of the bladder together and feed in through the hydraulic end opening (**Fig. 9**).
- Lightly screw the name plate and gas inlet valve sub-assembly nut on (**Fig. 10**).
- Check that the bladder is either folded or twisted.
- Insert the grid into the accumulator shell until it reaches its stop (**Fig. 11**).
- Reinstall the spring ring (**Fig. 12**).
- Before mounting the reduction on the hydraulic end, inflate the bladder slowly with nitrogen to a pressure of 1 - 1,5 bar with the tester and pressurizer instrument. Operate the tester and pressurizer instrument as described in its manual.
- Mount the flange or the reducing fitting (if existing).
- Tighten the name plate and gas inlet valve sub-assembly nut fully (**Fig. 13**).
- Inflate the accumulator to the precharge pressure required by the system.



Filling

- The first filling of the bladder with N₂ must be done slowly!

Volume accumulator	1 liter	5 liter	10 liter	50 liter	100 liter	200 liter
Filling time 0 to 1,5 bar in sec.	10 s	20 s	40 s	120 s	200 s	400 s

First operation

- Pressurise the system at maximum pressure and check the tightness of all connections and gaskets.
- **No welding/soldering or mechanical operations of any kind must be undertaken on the accumulators!**
- Hydropneumatic accumulatorss are subject to official pressure vessel regulations. These regulations demand that the accumulatorss must be inspected on a regular basis. The interval between inspections varies from state to state. Request the appertaining.